

Method 525.2

Date Extracted 5/10/02

Page 116

Lab #	Description	Sample vol/wt	Drip rate ml/min	Surr add	Spk add	IS add	Final vol.	T.V. pos.	pH	Count	SPE #	T.V.
	Lab Beh	944ml		1ml		10ml	1ml		5.2			
	Rel A				1ml							6A
	Rel B											6B
10997	Field Search										12	7A
10996	Sample									3	4	8A
10997	Sample									2	6	8B
	TW											6A
	TW-MS				1ml						6	8A
	TW-MSD										11	8B
11311	Sample									5	3	7B
11755	200R											
I don't have these samples as of SPE cartridges Lot # 0726001												
Remarks: used TW for MS and MSD - since there was not enough of samples 10996, 10997, 11311 for the MS and MSD.												
drip rate must be between 5-15 ml/min for liq-liq extractors												
Extraction type - <u>SPE</u> Solv. lot# <u>MC</u> NaCl lot# <u></u> Na2SO4 lot# <u>V 46648</u>												
STANDARD	INT STD LOG#											
CALIBRATION												
REF/SPIKE												
MDL/MDRF												
Q. CHECK												
INT. STD.												
SURROGATE												
LPC												
ENDRIN/DDT												

Analyst TB
revision 4/12/01

Verified by _____

Reviewed by _____
Date _____

Method 525.2

Instrument 213

File Directory 051302

Storage Directory

Lab #	Filename	Description	Vial #		Inj.	Standards used - Lot #			Int. Std.	Remarks	Initials
			front	rear		Calibration	Reference	Surrogate			
	MCA0513	MC	1		1						TV3
	MCIS0513	MC	2							with IS	
	MCISB0513	MC	3							" "	
	DFTA0513	DFTP	4			2164	2165				
	DDTA0513	DDT	5			2166					
	C5A0513	Cal 5	6			0204	29 CAL			based on cal	
	MCB0513	MC	7							of 5/8/02	
	LBA0513	Lab Bldg	8								
	REFA0513	Ref 1	9								
	REFB0513	" 2	10								
	MCC0513	MC	11								
	LBB0513	Lab Bldg	12								
	11311	Sample	13								
	10996	"	14								
	FR10997	Field Bldg	15								
	10997	Sample	16								
11755	TW0513	Tap water	17								
1	TWMS0513	TW MS	18								
1	TWMSD513	TW MSD	19								

Date 5/13/02

Extraction date 5/10/02
5/13/02

Page

Sequence Name: C:\MSDCHEM\1\SEQUENCE\051302.S

Comment:

Operator: Bohlk / Inst 213

Data Path: C:\MSDCHEM\1\DATA\051302\

Pre-Seq Cmd:

Post-Seq Cmd:

Method Sections To Run On A Barcode Mismatch

☒ Full Method ☒ Inject Anyway☐ Reprocessing Only ☐ Don't Inject

Line	Type	Vial	DataFile	Method	Sample Name
1	Sample	1	MCA0513	050802	MC
2	Sample	2	MCIS0513	050802	MC WITH IS
3	Sample	3	MCISB513	050802	MC WITH IS 5/13/02
4	Sample	4	DFTA0513	050802	DFTPP/ENDRIN
5	Sample	5	DDTA0513	050802	DDT
6	Sample	6	C5A0513	050802	CAL 5.0 UG/L
7	Sample	7	MCB0513	050802	MC
8	Sample	8	LBA0513	050802	LB 5/10/02
9	Sample	9	REFA0513	050802	REF1 5/10/02
10	Sample	10	REFB0513	050802	REF2 5/10/02
11	Sample	11	MCC0513	050802	MC
12	Sample	12	LBB0513	050802	LB 5/13/02
13	Sample	13	11311	050802	SAMPLE 11311 5/10/02
14	Sample	14	10996	050802	SAMPLE 10996 5/10/02
15	Sample	15	FB10997	050802	FB SAMPLE 10997 5/10/02
16	Sample	16	10997	050802	SAMPLE 10997 5/10/02
17	Sample	17	TW0513	050802	TAP WATER 5/10/02
18	Sample	18	TWMS0513	050802	TAP WATER MS 5/10/02
19	Sample	19	TWMSD513	050802	TAP WATER MSD 5/10/02